

# © CREATIVISION

## Home Entertainment & Personal Computing System



## CARTRIDGE INSTRUCTIONS

Congratulations! You've just opened a collection of the best professional software for diagnostic purpose.

## **CREATIVISION DIAGNOSTICART**

### **Getting ready**

You must check that everything is ready before you start operating. So go through the following checklist carefully:

- 1) Main unit antenna cable ... connected to TV ... Check!
- 2) Power cord ... plugged in ... Check!
- 3) TV ... plugged in ... Check!
- 4) Main unit power switch ... off ... Check!
- 5) Diagnosticart cartridge ... inserted ... Check!

Now move main unit power switch to ... ON!

Your TV screen should show one of the featured programs. If not, tune your TV until it appears, sharp and clear, on the screen.

### **KEYBOARD TEST**

An empty green screen is displayed. Type any key on the keyboard, move the sticks or press any button. If they work correctly, the letter or symbol is displayed on the screen. Gradually, the keyboard shows up on the screen. Press the Reset button to restart the test.

### **VIDEO TEST**

An empty green screen is displayed. Press any key to start the diagnostic procedure. Various tests are available, concerning a user-controlled sequence of text, patterns and colours, video modes, and sprites. Press the Reset button to restart the test.

### **VIDEO + AUDIO TEST**

A black screen with coloured vertical bands is displayed, with a scrolling explanatory message on the top area. Sounds are played using all 3 tonal channels and the noise channel of the sound generator chip. Press the Reset button to restart the test.